



Upgrade your machine with the latest software

To ensure support of the latest functions and optimum welding performance, we recommend that you always upgrade your welding power source to the latest available software. The software can be downloaded for free from our website www.migatronic.com or ordered as a software kit (article number 78861297).

1. Insert empty SD-card in your computer.



2. Go to www.migatronic.com and select the category "Software" in the "Support" menu. Choose "Software download for all machines".

The screenshot shows the Migatronik website's support page for software. The browser address bar shows <https://www.migatronic.com/en/support/product/software-5776>. The page has a navigation menu with 'Support', 'Cases', 'About', 'Contact', and 'Find a dealer'. A search bar is also present. The main content area is titled 'Software' and includes a sub-section 'Documents & downloads'. Under this section, there are several download options: 'Manual', 'Software', 'RCI configuration card', and 'Software history'. The 'Software' section is expanded, showing three items: 'Download licences to SD card' (0.29 MB), 'Software download - For all machines' (8.28 MB), and 'Software download - For non-standard machines (no welding program package)' (7.95 MB). Each item has a 'Download' button. A large black arrow points to the 'Download' button for the 'Software download - For all machines' option.

3. Run miga_sw_421.exe file that contains all relevant software in the latest version.

The screenshot shows a Windows file explorer window. The address bar shows <https://www.migatronic.com/en/support/product/software-5776>. The main content area is titled 'Software' and includes a sub-section 'Documents & downloads'. Under this section, there are several download options: 'Manual', 'Software', 'RCI configuration card', and 'Software history'. The 'Software' section is expanded, showing three items: 'Download licences to SD card' (0.29 MB), 'Software download - For all machines' (8.28 MB), and 'Software download - For non-standard machines (no welding program package)' (7.95 MB). Each item has a 'Download' button. A large black arrow points to the 'Download' button for the 'Software download - For all machines' option.


Hvad vil du foretage dig med miga_sw_421.exe (7.9 MB)?
Fra: migatronic.com

Kør Gem Annuller




Upgrade your machine with the latest software


4. Press the key "Browse" and make sure that the files are saved in the SD card folder on the computer. Unzip, when the correct folder has been selected.



5. Press the key "OK" and the SD-card will then be ready for use.



6. Upload software



**Are you having trouble with the upload?
Please verify SD-card (FAT32 format)**

